Micro-op Reduction (recall Processor 101)



Fewer uops per instruction allows IPC to be increased while lowering C dynamic (less bits and less toggling)

Power = C_{dynamic} * V * V * Frequency



