


Processor Power Pie-Chart: Another View

- High performance processors (prior/current generation) typically burn most of their power in the clocked latches and arrays (registers, caches).

(taken from: Bose, Martonosi, Brooks: Sigmetrics-2001 Tutorial)



Pre-silicon ckt-sim based; assumes: no clock-gating